



# **B**raemar

HEATING

COOLING



## ***GAS DUCTED HEATER TG3 SERIES***




## ***Home Owners Guide***

## GENERAL


### INTRODUCTION

Congratulations on choosing a Braemar Gas Ducted Heating Unit. Your Braemar Heater is built from the highest quality materials and is engineered to provide many years of trouble free performance.



**TG3**  
***Internal***

Please take a moment to read these instructions.



**TG3**  
***External***

### Delivery

The customer or installer, upon delivery of the heater should ensure that the model number and gas type is as requested. A data label on the end of the heater details both the model number and gas type. Please check the heater and report any freight damage.

### Features


1. Heat exchanger - 10 year warranty
2. Fully automatic electronic ignition
3. Approved by the Australian Gas Association
4. Three speed fan

Designed and manufactured in Australia to exacting standards.


# TURNING THE HEATER ON FOR THE FIRST TIME

Simply follow the steps below

PROGRAMMABLE T HERMOSTAT



MANUAL T HERMOSTAT



INCREASE  
TEMPERATURE

**Braemar**  
HEATING COOLING

## MAINTENANCE SCHEDULE

Periodic maintenance of the heater will ensure a long and satisfactory service life with the heater operating at optimum performance.

Maintenance should be performed on a yearly basis by an Authorised person trained in the service of the Braemar Heaters.

If heater does not operate satisfactorily refer to the trouble shooting chart below or contact your Braemar Dealer.

## TROUBLE SHOOTING

**If you have difficulty operating your Heater check the trouble shooting guide before calling for service**

### **Problem?**

HEAT should be ON but the heater is not working.

Check that gas is on to heater

Check that power is on to the heater

### **Problem?**

Heater has gone through a start-up sequence and has not lit.

Turn the Thermostat OFF-ON-OFF-ON with a 5 second interval between steps.

Set the thermostat temperature to above room temperature. The heater should now operate.

### **Problem?**

Heater is not operating effectively.

Check that there are enough outlets opened for the fan speed selected. Is the return air filter blocked ?

We recommend cleaning every fortnight.

### **Problem?**

Not enough Heating.

Is the thermostat located in the correct area according to the Installation Instructions.

Increase the SET temperature.

### **Problem?**

Heater runs when not programmed - Electronic thermostats.

Check the time AM or PM.

Sleep or away programmed temperature is too high: lower.

# IMPORTANT

Record the Serial No. and Model No. of the heater here.

Model No: \_\_\_\_\_

Serial No: \_\_\_\_\_

Date of Installation: \_\_\_\_/\_\_\_\_/\_\_\_\_

Installer: \_\_\_\_\_

## SERVICE

**Before calling for service have you :**

1. Checked through the trouble shooting guide.
2. Noted the Serial No. & Model No. of the heater.  
( if they are not recorded above, the numbers are located on the side of the heater. )
3. Spoken to your Braemar Dealer / Installer.

**FOR SERVICE CALL : 1 300 650 644**





**SERVICE: 1300 650 644**

For all your Braemar warranty and service needs.

Or

Contact your local Braemar direct dealer.

**TECHNICAL SUPPORT CENTRE: 1300 650 399**

For technical support regarding  
the installation of this product

**SALES: 1300 650 141**

For all your sales enquiries

Seeley International Pty Ltd has a policy of continuous product development and therefore reserves the right to make changes to these specifications without notice. Whilst every care has been taken to assure accuracy of the data compiled in the document, Seeley International Pty Ltd does not assume any liability for errors and/or omissions.

Braemar is a registered trademark of Braemar Industries Pty Ltd.

Seeley International Pty Ltd ACN 23 054 687 035

Albury Manufacturing

77 North Street Albury, NSW 2640



[www.seeley.com.au](http://www.seeley.com.au)